

## POWER SUNSHADE

### VOICE COMMANDS:

- Open Sunshade
- Close Sunshade
- Stop Moving
- Reset Sunshade

### IMPORTANT NOTES:

- Avoid using voice commands and switch simultaneously.
- If the unit isn't responding, use 'Reset Sunshade' to restart the system.
- Wait for the reset process to finish before using switch or voice control.

## AMBIENT LIGHTING

### GENERAL VOICE COMMANDS:

- **Hello Sunshade** - This command will reactivate the unit for further commands
- **Light On** - turns ambient lighting on
- **Light Off** - turns ambient lighting off
- **Switch Mode** - cycles through to the next color mode
- **Faster** or **Slow Down** - changes speed of some color modes

### COLOR MODE VOICE COMMANDS:

- **Auto Mode** - cycles full color array
- **Breathing Mode** - slow pulsing blue
- **Full Color Fluttering** - cycles full color gradient loop
- **Cool Mode** - twinkling fade between solid colors
- **Dream Mode** - fades between solid colors
- **Sports Mode** - cycles purple gradient loop
- **Flash Mode** - strobes between solid colors
- **Red Mode** - constant red
- **Golden Mode** - constant yellow
- **Green Mode** - constant green
- **Blue Mode** - constant blue
- **Purple Mode** - constant purple

 COOLSHADE<sup>PRO</sup>

